[t] 800.413.8783
805.494.0622
E-mail: service@sdcsecurity.com 801 Avenida Acaso, Camarillo, CA 93012
PO Box 3670, Camarillo, CA 93011

INSTALLATION INSTRUCTIONS


LR100VDK

ELECTRIC LATCH RETRACTION DEVICE KIT MODELS: 3327A, 3348A,3527A, 3548A, 9827, 9847, 9849, 9857, 9927, 9947, 9949, 9957 & 9975

Retrofit Installation Note: 42" or 48" exit devices that have been modified to fit a 36" or smaller opening, may not have the required space to fit the standard E. L. R. assembly. Always verify the distance from the end of the touchpad to the end rail, and if necessary, consult with the factory for appropriate selection.

Step 1


Remove Von Duprin installed mechanical dogging assembly.



ELECTRICAL DATA
24VDC +/- 10%
1.5A Inrush / 200mA holding
RED (+) BLK (-)
PATENT #8,851,530


* Visit: sdcsec.com/vonduprin
For Installation video

<u>Step 2</u> Slide the LR100 Electric Latch Retraction assembly into device and attach the linkage to the latch retraction rod.






Step 3 Tighten set screws.



INSTALLATION INSTRUCTIONS LR-1VD CONNECTING ROD FOR USE ON VON DUPRIN DEVICES LESS DOGGING FEATURE




When retrofitting to existing vertical rod devices, adjustment of the rods are required for proper assembly of the LR100VDK Kit.

Please see the SDC website (www.sdcsecurity.com) for installation tips and photographs of installing.

- 1. Remove the rail and push pad from the device
- 2. Drill a 5/32" (.156") diameter hole as shown in illustration.
- 3. Insert the connecting rod provided and fasten in screw




36" OPENING FULL LENGTH 36" DEVICE



Device head _

NOTE Retro-Fitting Vertical Rod Devices:

Before retro-fitting an electric latch assembly into a vertical device, the following must be done to ensure proper alignment. Disconnect the vertical rods from the device head. Install the electric latch assembly as shown above. Once the ELR is properly installed energize it so that the push pad is dogged down, by doing so it will allow for proper alignment for the vertical rods. Finally reconnect the vertical rods to the device and make the proper adjusments.



Disconnect vertical rods from the