

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 • www.sdcsecurity.com • E-mail: service@sdcsecurity.com

## LRPA1L / LRPA1R PAMEX INSTALLATION INSTRUCTIONS FIELD RETROFIT LATCH STATUS/REX SWITCH KIT

Remove Head Cover (For REX option remove head from device). Tap existing hole for 1/4-20. Replace existing pin with SDC P/N 5783. Attach switch assembly using the supplied 1/4-20 screw. Route wires thru extrusion as shown and use retaining clip to safely lock wires in place. Replace Head and Head Cover

