



[t] 800.413.8783
805.494.0622
E-mail: service@sdcsecurity.com
801 Avenida Acaso, Camarillo, CA 93012
PO Box 3670, Camarillo, CA 93011

INSTALLATION INSTRUCTIONS LRTS2R TOWN STEEL REQUEST-TO-EXIT SWITCH KIT MODEL: ED5500 SERIES

Remove the four screws at the front of the device (shown) and disconnect the head.



Remove the front two screws connecting the push pad to the housing. Route the wires along the side of the housing and out the back. Slide the LRTS2R into the housing <u>under</u> the push pad mounting bracket.



product are welcome. Please contact us through our website or email engineer@sdcsecurity.com