

[t] 800.413.8783
805.494.0622
E-mail: service@sdcsecurity.com 801 Avenida Acaso, Camarillo, CA 93012 PO Box 3670, Camarillo, CA 93011

INSTALLATION INSTRUCTIONS


LR100VDK-22 **ELECTRIC LATCH RETRACTION DEVICE KIT VON DUPRIN MODELS: 22 & 2227**

Step 1

Remove Von Duprin installed mechanical dogging assembly.

ELECTRICAL DATA

24VDC +/- 10% 1.5A Inrush / 200mA holding RED (+) BLK (-) PATENT #8,851,530



DOGGING ASSEMBLY

Device head

Disconnect vertical rods from the

NOTE Retro-Fitting Vertical Rod Devices:


Before retro-fitting an electric latch assembly into a vertical device, the following must be done to ensure proper alignment. Disconnect the vertical rods from the device head. Install the electric latch assembly as shown above. Once the ELR is properly installed energize it so that the push pad is dogged down, by doing so it will allow for proper alignment for the vertical rods. Finally reconnect the vertical rods to the device and make the proper adjusments.

Retrofit Installation Note: 42" or


48" exit devices that have been modified to fit a 36" or smaller opening, may not have the required space to fit the standard E. L. R. assembly. Always verify the distance from the end of the touchpad to the end rail, and if necessary, consult with the factory for appropriate selection.

Step 2

1. Slide the ELR assembly into the device rail.









Step 3

Carefully slide the ELR assembly back out until the linkage <u>JUST</u> makes contact with the latch retraction rod. Fasten down the 2 supplied set screws to secure the assembly to the device.



INSTALLATION INSTRUCTIONS LR-1VD CONNECTING ROD FOR USE ON VON DUPRIN DEVICES LESS DOGGING FEATURE



When retrofitting to existing vertical rod devices, adjustment of the rods are required for proper assembly of the LR100VDK Kit.

Please see the SDC website (www.sdcsecurity.com) for installation tips and photographs of installing.

- 1. Remove the rail and push pad from the device
- 2. Drill a 5/32" (.156") diameter hole as shown in illustration.
- 3. Insert the connecting rod provided and fasten in screw